ASSEMBLY AND INSTALLATION INSTRUCTIONS

H0260

WARNING: TO AVOID RISK OF ELECTRICAL SHOCK, BE SURE TO SHUT OFF POWER BEFORE INSTALLING OR SERVICING THIS FIXTURE.

NOTES: 1. Before installing, consult local electrical codes for wiring and grounding requirements.
2. READ AND SAVE THESE INSTRUCTIONS.

Hardware Package (included): Mounting Strap Unit (A) Mounting Screw (B) Wire Connector (C) Bolt Nut (D)

Installation Steps


Turn off the power at fuse or circuit box

- 1. Adjust the outer arms to the right angles.
- Secure rods into the couplings of the light.
- 3. Attach the mounting strap unit (A) to the outlet box using two mounting screws (B).
- 4. Rod Connections:
 - a. Thread the fixture wires from the fixture through the lower rod, and then secure the lower rod onto fixture using the threaded pipe.
 - b. Thread the fixture wires through the middle rod, and then secure the middle rod onto the lower rod using the threaded pipe.
 - c. Thread the fixture wires through the upper rod, and then secure the upper rod onto the middle rod using the threaded pipe.
 - d. Thread the fixture wires through the fixture canopy, and then secure fixture canopy onto the upper rod using the threaded pipe.

Note: Height adjustable from 31-3/4" to 73-3/4". Use fewer rods if shorter length is desired.

- 5. Pull out the source wires from the outlet box. Make wire connections using wire connectors (C) as follows:
 - ---Connect the smooth-coated wire (marked) from the fixture to the black wire from the power source.
 - ---Connect the ribbed-coated wire (unmarked) from the fixture to the white wire from the power source.
 - ---Attach the fixture ground wire to the mounting strap unit (A) with the green ground screw, then connect it to the house ground wire with a wire connector (C).


Carefully put the wires back into the outlet box.







- Attach the fixture canopy to the mounting strap unit (A) by inserting the fixture mounting screws, then secure it with two bolt nuts (D).
- Install 9pcs candelabra base bulbs (not included).
 Check relamping label at socket area or packaging for maximum wattage allowed.
- 8. Angled mounting recommended for a vaulted or angled ceiling. (See Fig. 1)

Turn on the power at fuse or circuit box



The following parts are available for re-order if damaged or missing.





A: 32"

B: 31-3/4"~73-3/4"

