
## ASSEMBLY AND INSTALLATION INSTRUCTIONS

P0346

## **WARNING:** TO AVOID RISK OF ELECTRICAL SHOCK, BE SURE TO SHUT OFF POWER BEFORE INSTALLING OR SERVICING THIS FIXTURE.

NOTE: 1. Before installing, consult local electrical codes for wiring and grounding requirements. 2. READ AND SAVE THESE INSTRUCTIONS.





- 5. Choose the length of the chain (L) you need, then weave the fixture wire and the fixture ground wire through the chain (L), collar (J) and canopy (H).
- 6. Connect one end of the chain (L) with the loop by using a loop lock (K).
- 7. Connect the other end of the chain (L) with the top loop (I) by using another loop lock (K).
- 8. Thread the fixture wire and fixture ground wire through the top loop (I), threaded pipe (E) and mounting strap (A).
- 9. Pull out the outlet wires and house ground wire from the outlet box. Make wire connections using the wire connectors (D):
  - ---The smooth wire (marked) from the fixture to the black wire from the power source.
  - ---The ridged wire (unmarked) from the fixture to the white wire from the power source.
  - ---Attach the fixture ground wire to the mounting strap (A) with the green ground screw (C). Then connect it to the house ground wire with a wire connector (D).


Carefully put the wires back into the outlet box.

- 10. Attach the canopy (H) to the mounting strap (A) by inserting the top loop (I), then secure it with the collar (J).
- 11. Install bulbs (not included). See relamping label at socket area or packaging for maximum wattage allowed .

Turn on the power at fuse or circuit box.

The following parts are available for re-order if damaged or missing.

Spare Parts List	<u>:</u>				
Mounting Strap (A)	ത്തായുന്നു അതാനു Mounting Screw (B)	අ Green Ground Screw (C)	Wire Connector (D)	Mounting Hardware 6276MM(1 SET)	
())))))))))) Threaded Pipe (E)	) Hex Nut (F)	🔘 Washer (G)	Canopy (H)	Chain (L)	
Top Loop (I)	Collar (J)	Loop Lock (K)		3219CB Glass Panel 9441CE	   (M)



A: 10-1/4" B: 7"

